



Feeler Strip Holder Item #236054

Thanks for purchasing our 236054 feeler strip holder. We've changed the design recently to improve the holding power of the tool and to help make it easier to change the feeler.



To use:

1. Pull the outer sleeve off the end of the shaft. The shaft is tapered, so the sleeve will only come off of the end it is mounted to.
2. Cut and place your feeler over the shaft.
3. Slide the locking sleeve over the shaft and the feeler. This locks the feeler securely.



Enjoy!

A handwritten signature in black ink that reads 'Jeff'.



901 Blairhill Road, Suite 400
Charlotte, NC 28217
800.659.6073 • 704.521.1088
www.jlsmithco.com

v.04.10